

STEP 1:

Fit the cradle to the bracket using the long bolts supplied but do not tighten the nuts



STEP 2:

Pull the cradle up away from the bracket to create a gap and insert the extenders into the gap. Be sure to fit the extenders the correct way round, they should be a snug fit with no gaps



STEP 3:

Tighten the bolts

