

MANUAL | USER GUIDE **WING**

READ THIS USER GUIDE CAREFULLY BEFORE USING YOUR BOARD

ASSUMPTION OF RISK

Use of the VAYU product and any of its components involves certain inherent risks, dangers, and hazards that can result in serious personal injury and death to both the user and to nonuser third parties. In using the VAYU product, you freely agree to assume and accept any and all known and unknown risks of injury to you and to third parties while using this equipment. The risks inherent in this sport can be greatly reduced by abiding the warning guidelines listed in this owner manual and by using common sense.

ty for any loss, damage, injury or expense

that you or any users of this product may

suffer, or that your next of kin may suffer,

any cause whatsoever, including negli-

design or manufacture of this product

as a result of the use of this product, due to

gence or breach of contract on the part of

VAYU Sports UG or any of its agents, in the

RELEASES AND WAIVER OF CLAIMS

In consideration of your use of this product, you hereby agree to the following, to the fullest extent permitted by law: To waive any and all claims that you have or may have in the future against VAYU Sports UG or any of its agents, resulting from use of this product and any of its components. To release VAYU Sports UG or any of its agents from any and all liabili-

BINDING EFFECT OF AGREEMENT

In the event of your death or incapacity, this Agreement shall be effective and binding upon your heirs, next of kin, executors, administrators, associates and representatives.

ENTIRE AGREEMENT

In entering into this Agreement, you are not relying upon any oral or written represen-

tations other than what is set forth in this agreement and User's Guide.

WARNING & SAFETY PRECAUTIONS

Wingfoiling can be a dangerous sport. Always use extreme caution when using this product. Misuse of this product can cause serious injury or death.

- Only use on unobstructed stretches on the water.
- Only fly the Foil Wing if you are a good swimmer and you are wearing a life jacket.
- You are responsible for your own safety and the safety of others around you when using this product.
- Use of this product exposes the user to unexpected and unavoidable risks, dangers and hazards.

THE LISTED RISKS CANNOT BE COMPLETED

The basic rules for foil wing foiling comply with those of common sense and are valid

for all outdoor sports.

FITTING THE FOOTSTRAPS ONTO THE BOARD

If you are not sure which position you prefer, choose the central position as a first reference. Use the screws provided. Fasten the screw through the foot strap into the plastic insert of the board. Watch the angle of the screw to avoid damaging the board.

- Never use this product in thunderstorm and lightning conditions.
- Never use this product in wind conditions that are above your ability level.
- Make sure you take lessons from a Wingfoiling school before using this product on-the-water.
- Always observe local rules and regulations when using this product.
- Make sure to always stay 100 m away from obstructions.
- Never use this product without a leash.

INFLATING THE WING



STEP 1: Lay the wing down on a surface, free of hard or sharp objects, as they could damage it. Turn the wing with the strut facing up. Make sure the leading edge is facing towards the wind.



STEP 2: Attach the pump leash to the leash connection point on the leading edge.



STEP 3: Open the neopren valve cover.



STEP 4: Turn the cap to open the valve.



STEP 5: Connect the hose to the valve.




STEP 6: Use a pump with gauge, inflate the kite to the recommended 6 psi.



STEP 7: Remove the hose from the valve and tighten up the cap by turning it clockwise to the closed position and close the neopren cover.


DEFLATING THE WING





STEP 2: Unscrew the valve.

ASSEMBLY DIAGRAM



FOIL WING CARE

- Avoid bringing the foil wing into contact with sharp-edged rocks, thorns, wood and other objects that may damage, puncture or tear the cloth.
- Do not expose the foil wing to excessive sun as it ages the material unnecessarily.
- Deflate the bladders if the foil wing is to be left unattended for any length of time.
- Avoid leaving your foil wing on the beach for extended lengths of time as small wind movements may quickly cause wear and tear to the cloth.
- Try to pack up the foil wing into the bag without cuttings to avoid tearing the canopy.
- To carry a foil wing, turn it so that the leading edge is upwind and the underside faces upwards.
- Grab the centre of the leading edge tube. If the wind is blowing, it will hold the foil

wing clear of the ground. Be sure not to drag the tips of the foil wing across the ground.

- A coating that results from using the foil wing in salt water will not damage the foil wing. However, rinsing in fresh water and drying is recommended.
- When cleaning the foil wing be sure that no water, dirt, or sand gets inside the bladders.
- Be sure that the foil wing has dried completely before packing it up. Otherwise changes of color or mildew could occur. Such bleeding is not covered under the VAYU warranty.
- Do not dry the foil wing in direct sun!
- Keep sand and water out of the air pump.

- VAYU Warrants this product to be free of major defects in material or workmanship to the original purchaser for a period of six months from the original date of purchase. This warranty is subject to the following limitations: The warranty is valid only when the product is used for foil wing foiling on water and does not cover products used in rental or teaching operations.
- VAYU will make the final warranty determination, which may require inspection and/or photos of the equipment, which clearly show the defect(s). If necessary, this information must be sent to the VAYU distributor in your country, postage prepaid.
- If a product is deemed to be defective by VAYU, the warranty covers the repair or replacement of the defective product only.
- VAYU will not be responsible for any costs, losses or damages incurred as a

WARRANTY CLAIMS

Warranty claims must be processed and be issued and a return authorization must be issued prior to VAYU. result of loss of use of this product. The warranty does not cover damage caused by misuse, abuse, neglect or normal wear and tear including but not limited to, rigging with other than VAYU components, damage due to excessive sun exposure, damage caused by improper handling or storage, damage caused by use in the waves or shore break and damage caused by anything other than defects in material and workmanship.

 This warranty expires if any unauthorized repair, change or modification has been made to any part of the equipment. The warranty for any repaired or replaced equipment is valid as of the date of the original purchase only. The original purchase receipt must accompany all warranty claims. The name of the retailer and date of purchase must be clear and legible. There are no warranties that extend beyond the warranty specified herein.



contact: support@vayu.world

GERMANY

Kiel Koppelberg 4-6, 24159

SPAIN

San Sebastian Avenida Navarra 50, 20013

USA

Portland SE Ankeny 3463, 97214 US